



HYPERCOM T7 SERIES ENABLE PRINTER

Press Func 71, Enter to enable printer
Press Func 72, Enter to run a test print

If the above steps do not work, follow these steps.

Go into boot mode by unplugging the power and holding down "card Verify",
"void", and "offline" and plugging the power back in until the screen displays
"please initialize or call help - XX"

Press Func 99, Enter
Press 3, Enter
Press Enter 20 times to get to Printer Type.
Change to '01' for thermal or '0A' for Friction, Enter

Press Cancel

Press Func 99, Enter
Press 9, Enter
Press 3, Enter

"Writing Eeprom..."

Press Cancel

Press Func 3, Enter to re-boot
Press Func 72, Enter to re-print

Func 82, Enter

Press Cancel