

Download Procedures and Terminal Setup

4

Full Download Procedure – H32P14R and H32P14S

A download of the Omni 3200 Petroleum/Auto Services/Retail terminal takes approximately 45 minutes to complete. Before a terminal can receive a download, you must prepare it to accept the download by performing the following steps.

When keying in the password, no numbers will appear on the display. If the terminal does not have its own phone line, instruct the merchant to hang up before pressing [ENTER] on Step 11.

Step	Display	Action	Key(s)
1	I D L E P R O M P T	Press:	[ENTER] AND [7] SIMULTANEOUSLY
2	SYSTEM PASSWORD?	Key:	Z66831
3	* * * * *	Press:	[ENTER]
4	SYSTEM = V.....	Press:	[BACKSPACE]
5	MEMORY TEST... PRESS ENTER TO CONTINUE	Press:	[ENTER]
6	MEMORY OK	Press:	[CLEAR] UNTIL YOU SEE "SYSTEM" AGAIN.
7	SYSTEM = V.....	Press:	[0]
8	*ZP=	Key:	THE DOWNLOADER TELEPHONE NUMBER AND PRESS [ENTER].
9	*ZT=	Key:	THE DOWNLOAD FILE NAME AND PRESS [ENTER].
10	*ZA=	Key:	THE APPLICATION NAME AND PRESS [ENTER].
11	PARTIAL OR FULL?	Press:	[ENTER]
12	* - - - - -	No action while downloading.	
13	DOWNLOAD DONE	Press:	[CLEAR]

Partial Download Procedure – H32P14R and H32P14S

Partial downloads are used to change a select few memory locations that are already programmed in the terminal. A few examples of information that could be changed through a partial download are the printer/header information or card services.

Step	Display	Action	Key(s)
1	I D L E P R O M P T	Press:	[ENTER] AND [7] SIMULTANEOUSLY
2	S Y S T E M P A S S W O R D ?	Key:	Z66831
3	* * * * *	Press:	[ENTER]
4	S Y S T E M = V . . .	Press:	[0]
5	P A R T I A L O R F U L L ?	Press:	[*]
6	* - - - - -	Press:	NO ACTION WHILE DOWNLOADING
7	D O W N L O A D D O N E	Press:	[CLEAR]

Key Functions - H32P14R

The following are the keys on the Paymentech Omni 3200 terminal utilizing the H32P14R application.

Key	Transaction Type
[F2]	Sale
[F3]	Admin
[F4]	Shift or Batch
[ARROW, F1]	Void
[ARROW, F2]	Return
[ARROW, F3]	Prior Auth Sale
[ARROW, F4]	EBT
[ARROW, ARROW, F1]	Auth Only
[ARROW, ARROW, F2]	Terminal Maintenance
[ARROW, ARROW, F3]	Terminal Setup
[ARROW, ARROW, F4]	System Detail
[ARROW, ARROW, ARROW, F1]	Set Clock
[ARROW, ARROW, ARROW, F2]	Test Card Swipe
Left to Right	
[1]	ARROW
[2]	REPRINT
[3]	BATCH REPORTS
[4]	ADMIN REPORTS

Key Functions - H32P14S

The following are the keys on the Paymentech Omni 3200 terminal utilizing the H32P14S application.

Key	Transaction Type
[F2]	Sale
[F3]	Admin
[F4]	Stored Value
[ARROW, F1]	Shift or Batch
[ARROW, F2]	Void
[ARROW, F3]	Return
[ARROW, F4]	Prior Authorized Sale
[ARROW, ARROW, F1]	EBT
[ARROW, ARROW, F2]	Authorization Only
[ARROW, ARROW, F3]	Terminal Maintenance
[ARROW, ARROW, F4]	Terminal Setup
[ARROW, ARROW, ARROW F1]	System Detail
[ARROW, ARROW, ARROW F2]	Set Clock
[ARROW, ARROW, ARROW F3]	Test Card Swipe
Left to Right	
[1]	ARROW
[2]	REPRINT
[3]	BATCH REPORTS
[4]	ADMIN REPORTS

Terminal Setup Mode - H32P14R

To access and make changes in the terminal setup mode, please use the following steps.

Printers/Headers - H32P14R

Step	Display	Action	Key(s)
1	Idle Prompt	Press:	[ARROW]
2	Void Return Prior Auth Sale EBT	Press:	[ARROW]
3	Auth Only Terminal Maint. Terminal Setup System Detail	Press:	[F3]
4	Print Config. Printer/Headers Prompts Phone Numbers	Press:	[F2]
5	Printer PIN Pad Encryption RCPT 2 Delay	Press:	[F1]
6	Printer Printer On 0-Off 1-On	Key:	[0] - OFF [1] - ON PRESS [ENTER] TO RETURN TO PREVIOUS MENU
7	Printer PIN Pad Encryption RCPT 2 Delay	Press:	[F2]
8	PIN Pad PIN Pad - On 0-Off 1-On	Key:	[0] - OFF [1] - ON PRESS [ENTER] TO RETURN TO PREVIOUS MENU
9	Printer PIN Pad Encryption RCPT 2 Delay	Press:	[F3]
10	Encryption Encryption-DUKPT 0-Masterkey 1- DUKPT	Key:	[0] - MASTERKEY [1] - DUKPT PRESS [ENTER] TO RETURN TO PREVIOUS MENU

Step	Display	Action	Key(s)
11	Printer PIN Pad Encryption Rcpt 2 Del ay	Press:	[F4]
12	Rcpt 2 Del ay 5	Key:	NONE PRESS [ENTER] TO RETURN TO PREVIOUS MENU
13	Printer PIN Pad Encryption RCPT 2 Del ay	Press:	[ARROW]
14	Recei pt Opti ons Print 2 Reports DBT/EBT Cash Back Print Headers	Press:	[F1]
15	Recei pt Opti ons Recei pt opti ons M&C 0-None 1-M&C 2-MO 3-C	Key:	[0] - None [1] - M&C [2] - MO [1] - C PRESS [ENTER] TO RETURN TO PREVIOUS MENU
16	Printer PIN Pad Encryption RCPT 2 Del ay	Press:	[ARROW]
17	Recei pt Opti ons Print 2 Reports DBT/EBT Cash Back Print Headers	Press	[F2]
18	Print 2 Recei pts Print 2 Recei pts- Off 0-Off 1-On	Key:	[0] - OFF [1] - ON PRESS [ENTER] TO RETURN TO PREVIOUS MENU
19	Printer PIN Pad Encryption RCPT 2 Del ay	Press:	[ARROW]
20	Recei pt Opti ons Print 2 Reports DBT/EBT Cash Back Print Headers	Press:	[F3]
21	DBT/EBT Cash Back DBT/EBT Cash Back- No 0-No 1-Yes	Key:	[0] - NO [1] - YES PRESS [ENTER] TO RETURN TO PREVIOUS MENU
22	Printer PIN Pad Encryption RCPT 2 Del ay	Press:	[ARROW]

Step	Display	Action	Key(s)
23	Recei pt Opti ons Pri nt 2 Reports Debi t Cash Back Pri nt Headers	Press:	[F4]
24	Pri nt Headers Header #1 Merch ant Number	Key:	MERCHANT NUMBER PRESS [ENTER] TO EDIT NEXT OPTION
25	Header #2 Merch ant Address	Key:	MERCHANT ADDRESS PRESS [ENTER] TO EDIT NEXT OPTION
26	Header #3 Merch ant Ci ty St ate Zi p Code	Key:	MERCHANT CITY, STATE ZIP CODE PRESS [ENTER] TO EDIT NEXT OPTION
27	Header #4 Merch ant Phone	Key:	MERCHANT PHONE NUMBER PRESS [ENTER] TO EDIT NEXT OPTION
28	Header #5 Merch ant Data	Key:	MERCHANT DATA PRESS [ENTER] TO EDIT NEXT OPTION
29	Header #6 Merch ant Data	Key:	MERCHANT DATA PRESS [ENTER] TO RETURN TO PRINT HEADERS MENU
30	Pri nter PI N Pad Encry pti on RCPT 2 Del ay	Press:	[ARROW]
31	Recei pt Opti ons Pri nt 2 Reports DBT/EBT Cash Back Pri nt Headers	Press:	[ARROW]
32	Pri nt Di scl ai mer Pri nter Footers Cust Copy Si gn	Press:	[F1]
33	Pri nt Di scl ai mrs Di scl ai mer #1	Key:	ENTER IN DISCLAIMER #1 PRESS [ENTER] TO EDIT NEXT OPTION
34	Pri nt Di scl ai mrs Di scl ai mer #2	Key:	ENTER IN DISCLAIMER #2 PRESS [ENTER] TO EDIT NEXT OPTION
35	Pri nt Di scl ai mrs Di scl ai mer #3	Key:	ENTER IN DISCLAIMER #3 PRESS [ENTER] TO EDIT NEXT OPTION

Step	Display	Action	Key(s)
36	Printer PIN Pad Encryption RCPT 2 Delay	Press:	[ARROW]
37	Receipt Options Print 2 Reports DBT/EBT Cash Back Print Headers	Press:	[ARROW]
38	Print Disclaimer Printer Footers Cust Copy Sign	Press:	[F2]
39	Print Footers Footer #1 Merchant Data	Key:	ENTER MERCHANT DATA PRESS [ENTER] TO EDIT NEXT OPTION
40	Print Footers Footer #2 Merchant Data	Key:	ENTER MERCHANT DATA PRESS [ENTER] TO EDIT NEXT OPTION
41	Print Footers Footer #3 Merchant Data	Key:	ENTER MERCHANT DATA PRESS [ENTER] TO EDIT NEXT OPTION
42	Print Footers Footer #4 Merchant Data	Key:	ENTER MERCHANT DATA PRESS [ENTER] TO EDIT NEXT OPTION
43	Printer PIN Pad Encryption RCPT 2 Delay	Press:	[ARROW]
44	Receipt Options Print 2 Reports DBT/EBT Cash Back Print Headers	Press:	[ARROW]
45	Print Disclaimer Printer Footers Cust Copy Sign	Press:	[F3]
46	Cust Copy Sign Cust Copy Sign-On 0-Off 1-On	Press:	[0]-OFF [1]-ON PRESS [ENTER] TO RETURN TO PREVIOUS MENU

Prompts - H32P14R

Step	Display	Action	Key(s)
1	Idle Prompt	Press:	[ARROW]
2	Void Return Prior Auth Sale EBT	Press:	[ARROW]
3	Auth Only Terminal Maint. Terminal Setup System Detail	Press:	[F3]
4	Print Config. Printer/Headers Prompts Phone Numbers	Press:	[F3]
5	App Mode PINPad Prompt Ask For Serv Ask For Gallons	Press:	[F1]
6	App Mode App Mode-Petro 0-Petro 1-Retail 2-Rest	Key:	[0]-PETRO APPLICATION [1]-RETAIL [2]-RESTAURANT PRESS [ENTER] TO RETURN TO PREVIOUS MENU
7	App Mode PINPad Prompt Ask For Serv Ask For Gallons	Press:	[F2]
8	PIN Pad Prompt Welcome	Key:	PIN PAD IDLE PROMPT PRESS [ENTER] TO RETURN TO PROMPTS MENU
9	App Mode PINPad Prompt Ask For Serv Ask For Gallons	Press:	[F3]
10	Ask For Serv Ask For Serv-Yes 0-No 1-Yes	Key:	ASK FOR SERVE - YES 0 - NO 1 - YES PRESS [ENTER] TO RETURN TO PROMPTS MENU
11	App Mode PINPad Prompt Ask For Serv Ask For Gallons	Press:	[F4]

Step	Display	Action	Key(s)
12	Ask For Gal l ons Ask For Gal l ons-None 0-None 1-GC Onl y 2-All	Key:	ASK FOR GALLONS-NONE 0-NONE 1-GC ONLY 2-All PRESS [ENTER] TO RETURN TO PROMPTS MENU
13	App Mode PI NPad Prompt Ask For Serv Ask For Gal l ons	Press:	[ARROW]
14	Prompt For Tax Keyboard Beep Ti meout SV MOD 10 Check	Press:	[F1]
15	Prompt for Tax Prompt for Tax-No 0-No 1-Yes	Key:	[0] - NO [1] - YES PRESS [ENTER] TO RETURN TO PROMPTS MENU
16	Prompt For Tax Keyboard Beep Ti meout SV MOD 10 Check	Press:	[F2]
17	Keyboard Beep Keyboard Beep-On 0-Off 1-On	Key:	[0] - OFF [1] - ON PRESS [ENTER] TO RETURN TO PROMPTS MENU
18	Prompt For Tax Keyboard Beep Ti meout SV MOD 10 Check	Press:	[F3]
19	Ti meout 60	Press:	TIMEOUT VALUE PRESS [ENTER] TO RETURN TO PROMPTS MENU
20	Prompt For Tax Keyboard Beep Ti meout SV MOD 10 Check	Press:	[F4]
21	SV MOD 10 Check SV MOD 10 Check Yes 0- NO 1-Yes	Key:	[0] = NO [1] = YES PRESS [CLEAR] TO RETURN TO PROMPTS MENU
22	App Mode PI NPad Prompt Ask For Serv Ask For Gal l ons	Press:	[ARROW]
23	Prompt For Tax Keyboard Beep Ti meout SV MOD 10 Check	Press:	[ARROW]

Step	Display	Action	Key(s)
24	SV Cash out Ask Last 4 Di gi t Ask Ask Press Send Cust Ref #	Press:	[F1]
25	SV Cash Out Ask SV Cash Out Ask-No 0-No 1-Yes	Key:	[0] = NO [1] = YES PRESS [CLEAR] TO RETURN TO PROMPTS MENU
26	App Mode PI NPad Prompt Ask For Serv Ask For Gal l ons	Press:	[ARROW]
27	Prompt For Tax Keyboard Beep Ti meout SV MOD 10 Check	Press:	[ARROW]
28	SV Cash out Ask Last 4 Di gi t Ask Ask Press Send Cust Ref #	Press:	[F2]
29	Last 4 Di gi t Ask Last 4 Di gi t Ask- Yes 0-No 1-Yes	Key:	[0] = NO [1] = YES PRESS [CLEAR] TO RETURN TO PROMPTS MENU
30	App Mode PI NPad Prompt Ask For Serv Ask For Gal l ons	Press:	[ARROW]
31	Prompt For Tax Keyboard Beep Ti meout SV MOD 10 Check	Press:	[ARROW]
32	SV Cash out Ask Last 4 Di gi t Ask Ask Press Send Cust Ref #	Press:	[F3]
33	Ask for Serv Ask for Serv-No 0-No 1-Yes	Key:	[0] = NO [1] = YES PRESS [CLEAR] TO RETURN TO PROMPTS MENU
34	App Mode PI NPad Prompt Ask For Serv Ask For Gal l ons	Press:	[ARROW]
35	Prompt For Tax Keyboard Beep Ti meout SV MOD 10 Check	Press:	[ARROW]
36	SV Cash out Ask Last 4 Di gi t Ask Ask Press Send Cust Ref #	Press:	[F4]

Step	Display	Action	Key(s)
37	Cust Ref # Cust Ref #- No 0-No 1-Yes	Key:	[0] = NO [1] = YES PRESS [CLEAR] TO RETURN TO PROMPTS MENU

Phone Numbers - H32P14R

Step	Display	Action	Key(s)
1	Idle Prompt	Press:	[ARROW]
2	Void Return Prior Auth Sale EBT	Press:	[ARROW]
3	Auth Only Terminal Maint. Terminal Setup System Detail	Press:	[F3]
4	Print Config. Printer/Headers Prompts Phone Numbers	Press:	[F4]
5	Primary Phone # Alt Phone # Download Phone #	Press:	[F1]
6	Primary Phone # *****	Key:	PRIMARY PHONE NUMBER
7	Primary Phone Number	Press:	[ENTER]
8	Primary Phone # Alt Phone # Download Phone #	Press:	[F2]
9	Alt Phone # *****	Key:	ALTERNATE PHONE NUMBER
10	Alternate Phone Number	Press:	[ENTER]
11	Primary Phone # Alt Phone # Download Phone #	Press:	[F3]
12	Download Phone # 18003629020	Press:	[CLEAR] TO RETURN TO IDLE PROMPT

Dial Type - H32P14R

Step	Display	Action	Key(s)
1	Idle Prompt	Press:	[ARROW]
2	Void Return Prior Auth Sale EBT	Press:	[ARROW]
3	Auth Only Terminal Maint. Terminal Setup System Detail	Press:	[F3]
4	Print Config. Printer/Headers Prompts Phone Numbers	Press:	[ARROW]
5	Comm/Dial Merchant Info Product Key Map Setup BIN Table	Press:	[F1]
6	Comm Type Dial Type Dial Speed Modem Speed	Press:	[F1]
7	Comm Type Comm Type-Dial 0-Dial 1-DTR 2-AT	Press:	0-DIAL 1-DTR 2-AT PRESS [ENTER] TO RETURN TO COMM/DIAL MENU
8	Comm Type Dial Type Dial Speed Modem Speed	Press:	[F2]
9	Dial Type Dial Type-Tone 0-Pulse 1-Tone	Key:	[0] - PULSE [1] - TONE PRESS [ENTER] TO RETURN TO COMM/DIAL MENU
10	Comm Type Dial Type Dial Speed Modem Speed	Press:	[F3]
11	Dial Speed Dial Speed-Slow 0-Slow 1-Fast	Key:	[0] - SLOW [1] - FAST PRESS [ENTER] TO RETURN TO COMM/DIAL MENU
12	Comm Type Dial Type Dial Speed Modem Speed	Press:	[F4]

Step	Display	Action	Key(s)
13	Modem Speed Modem Speed- 1200 0- 300 1- 1200	Key:	[0] - 300 [1] - 1200 PRESS [ENTER] TO RETURN TO COMM/DIAL MENU
14	Comm Type Di al Type Di al Speed Modem Speed	Press:	[ARROW]
15	Seri al Num Predi al	Press:	[F1]
16	Seri al Num *****	Key:	DOWNLOAD FILE NAME PRESS [CLEAR] TO RETURN TO IDLE PROMPT
17	Comm Type Di al Type Di al Speed Modem Speed	Press:	[ARROW]
18	Seri al Num Predi al	Press:	[F2]
19	Predi al ? Predi al ? No 0-No 1- Yes	Key:	[0] = NO [1] = YES

Merchant Info - H32P14R

Step	Display	Action	Key(s)
1	Idle Prompt	Press:	[ARROW]
2	Void Return Prior Auth Sale EBT	Press:	[ARROW]
3	Auth Only Terminal Maint. Terminal Setup System Detail	Press:	[F3]
4	Print Config. Printer/Headers Prompts Phone Numbers	Press:	[ARROW]
5	Comm/Dial Merchant Info Product Keymap Setup BIN Table	Press:	[F2]
6	Client # Merchant # Terminal #	Press:	[F1]
7	Client # ****	Key:	4-DIGIT PNS CLIENT NUMBER PRESS [ENTER] TO EDIT NEXT OPTION
8	Client # Merchant # Terminal #	Press:	[F2]
9	Merchant # *****	Key:	12-DIGIT PNS MERCHANT NUMBER PRESS [ENTER] TO EDIT NEXT OPTION
10	Client # Merchant # Terminal #	Press:	[F3]
11	Terminal # ***	Key:	3-DIGIT TERMINAL ID PRESS [CLEAR] TO RETURN TO IDLE PROMPT

Product Key Map - H32P14R

Step	Display	Action	Key(s)
1	Idle Prompt	Press:	[ARROW TWICE]
2	Auth Only Terminal Maint. Terminal Setup System Detail	Press:	[F3]
3	Print Config. Printer/Headers Prompts Phone Numbers	Press:	[ARROW]
4	Comm/Dial Merchant Info Product Keymap Setup BIN Table	Press:	[F3]
5	Product Key Map KEY #1 0	Key:	PRODUCT CODE KEY SHOULD EQUAL
6	Product Code Key Should Equal	Press:	[ENTER]
7	Product Key Map KEY #2 2	Key:	PRODUCT CODE KEY SHOULD EQUAL
8	Product Code Key Should Equal	Press:	[ENTER]
9	Product Key Map KEY #3 3	Key:	PRODUCT CODE KEY SHOULD EQUAL
10	Product Code Key Should Equal	Press:	[ENTER]
11	Product Key Map KEY #4 4	Key:	PRODUCT CODE KEY SHOULD EQUAL
12	Product Code Key Should Equal	Press:	[ENTER]
13	Product Key Map KEY #5 5	Key:	PRODUCT CODE KEY SHOULD EQUAL
14	Product Code Key Should Equal	Press:	[ENTER]
15	Product Key Map KEY #6 6	Key:	PRODUCT CODE KEY SHOULD EQUAL
16	Product Code Key Should Equal	Press:	[ENTER]
17	Product Key Map KEY #7 7	Key:	PRODUCT CODE KEY SHOULD EQUAL
18	Product Code Key Should Equal	Press:	[ENTER]

Step	Display	Action	Key(s)
19	Product Key Map KEY #88	Key:	PRODUCT CODE KEY SHOULD EQUAL
20	Product Code Key Shoul d Equal	Press:	[ENTER]
21	Product Key Map KEY #9 9	Key:	PRODUCT CODE KEY SHOULD EQUAL
22	Product Code Key Shoul d Equal	Press:	[CLEAR] TO RETURN TO IDLE PROMPT

Setup BIN Tables - H32P14R

Step	Display	Action	Key(s)
1	Idle Prompt	Press:	[ARROW]
2	Void Return Prior Auth Sale EBT	Press:	[ARROW]
3	Auth Only Terminal Maint. Terminal Setup System Detail	Press:	[F3]
4	Print Config. Printer/Headers Prompts Phone Numbers	Press:	[ARROW]
5	Comm/Dial Merchant Info Product Keymap Setup BIN Table	Press:	[F4]
6	Setup BIN Table Debit = Capture 0 Not Acpt 1 Auth Only	Key:	[0] - NOT ACCEPT [1] - AUTH ONLY [2] - CAPTURE PRESS [ENTER] TO EDIT NEXT BIN RANGE
7	Setup BIN Table EBT = Capture 0 Not Acpt 1 Auth Only	Key:	[0] - NOT ACCEPT [1] - AUTH ONLY [2] - CAPTURE PRESS [ENTER] TO EDIT NEXT BIN RANGE
8	Setup BIN Table Stored Value = Capture 0 Not Acpt 1 Auth Only	Key:	[0] - NOT ACCEPT [1] - AUTH ONLY [2] - CAPTURE PRESS [ENTER] TO EDIT NEXT BIN RANGE
9	Setup BIN Table MasterCard = Capture 0 Not Acpt 1 Auth Only	Key:	[0] - NOT ACCEPT [1] - AUTH ONLY [2] - CAPTURE PRESS [ENTER] TO EDIT NEXT BIN RANGE
10	Setup BIN Table Visa = Capture 0 Not Acpt 1 Auth Only	Key:	[0] - NOT ACCEPT [1] - AUTH ONLY [2] - CAPTURE PRESS [ENTER] TO EDIT NEXT BIN RANGE

Step	Display	Action	Key(s)
11	Setup BIN Table Visa = Capture 0 Not Acpt 1 Auth Only	Key:	[0] - NOT ACCEPT [1] - AUTH ONLY [2] - CAPTURE PRESS [ENTER] TO EDIT NEXT BIN RANGE
12	Setup BIN Table MasterCard = Capture 0 Not Acpt 1 Auth Only	Key:	[0] - NOT ACCEPT [1] - AUTH ONLY [2] - CAPTURE PRESS [ENTER] TO EDIT NEXT BIN RANGE
13	Setup BIN Table AMEX = Capture 0 Not Acpt 1 Auth Only	Key:	[0] - NOT ACCEPT [1] - AUTH ONLY [2] - CAPTURE PRESS [ENTER] TO EDIT NEXT BIN RANGE
14	Setup BIN Table AMEX = Capture 0 Not Acpt 1 Auth Only	Key:	[0] - NOT ACCEPT [1] - AUTH ONLY [2] - CAPTURE PRESS [ENTER] TO EDIT NEXT BIN RANGE
15	Setup BIN Table Discover = Capture 0 Not Acpt 1 Auth Only	Key:	[0] - NOT ACCEPT [1] - AUTH ONLY [2] - CAPTURE PRESS [ENTER] TO EDIT NEXT BIN RANGE
16	Setup BIN Table Diners = Capture 0 Not Acpt 1 Auth Only	Key:	[0] - NOT ACCEPT [1] - AUTH ONLY [2] - CAPTURE PRESS [ENTER] TO EDIT NEXT BIN RANGE
17	Setup BIN Table Diners = Capture 0 Not Acpt 1 Auth Only	Key:	[0] - NOT ACCEPT [1] - AUTH ONLY [2] - CAPTURE PRESS [ENTER] TO EDIT NEXT BIN RANGE

Step	Display	Action	Key(s)
18	Setup BIN Table Diners = Capture 0 Not Acpt 1 Auth Only	Key:	[0] - NOT ACCEPT [1] - AUTH ONLY [2] - CAPTURE PRESS [ENTER] TO EDIT NEXT BIN RANGE
19	Setup BIN Table Carte Bl an = Capture 0 Not Acpt 1 Auth Only	Key:	[0] - NOT ACCEPT [1] - AUTH ONLY [2] - CAPTURE PRESS [ENTER] TO EDIT NEXT BIN RANGE
20	Setup BIN Table JCB = Capture 0 Not Acpt 1 Auth Only	Key:	[0] - NOT ACCEPT [1] - AUTH ONLY [2] - CAPTURE PRESS [ENTER] TO EDIT NEXT BIN RANGE
21	Setup BIN Table JCB = Capture 0 Not Acpt 1 Auth Only	Key:	[0] - NOT ACCEPT [1] - AUTH ONLY [2] - CAPTURE PRESS [ENTER] TO EDIT NEXT BIN RANGE
22	Setup BIN Table Wright EXP = Capture 0 Not Acpt 1 Auth Only	Key:	[0] - NOT ACCEPT [1] - AUTH ONLY [2] - CAPTURE PRESS [ENTER] TO EDIT NEXT BIN RANGE
23	Setup BIN Table Wright EXP = Capture 0 Not Acpt 1 Auth Only	Key:	[0] - NOT ACCEPT [1] - AUTH ONLY [2] - CAPTURE PRESS [ENTER] TO EDIT NEXT BIN RANGE
24	Setup BIN Table Voyager = Capture 0 Not Acpt 1 Auth Only	Key:	[0] - NOT ACCEPT [1] - AUTH ONLY [2] - CAPTURE PRESS [ENTER] TO EDIT NEXT BIN RANGE

Step	Display	Action	Key(s)
25	Setup BIN Table IRVING OI I =Not Acpt 0 Not Acpt 1 Auth Only	Key:	[0] - NOT ACCEPT [1] - AUTH ONLY [2] - CAPTURE PRESS [ENTER] TO EDIT NEXT BIN RANGE

Functions On/Off - H32P14R

Step	Display	Action	Key(s)
1	Idle Prompt	Press:	[ARROW]
2	Void Return Prior Auth Sale EBT	Press:	[ARROW]
3	Auth Only Terminal Maint. Terminal Setup System Detail	Press:	[F3]
4	Print Config. Printer/Headers Prompts Phone Numbers	Press:	[ARROW]
5	Comm/Dial Merchant Info Product Keymap Setup BIN Table	Press:	[ARROW]
6	Functions On/Off Passwords On/Off Duplicate Check	Press:	[F1]
7	Credit Sale Debit Sale Void Return	Press:	[F1]
8	Credit Sale Credit Sale - On 0-On 1-Off	Key:	[0] - ON [1] - OFF PRESS [ENTER] TO EDIT NEXT FUNCTION
9	Credit Sale Debit Sale Void Return	Press:	[F2]
10	Debit Sale Debit Sale On 0-On 1-Off	Key:	[0] - ON [1] - OFF PRESS [ENTER] TO EDIT NEXT FUNCTION
11	Credit Sale Debit Sale Void Return	Press:	[F3]
12	Void Void On 0-On 1-Off	Key:	[0] - ON [1] - OFF PRESS [ENTER] TO EDIT NEXT FUNCTION
13	Credit Sale Debit Sale Void Return	Press:	[F4]

Step	Display	Action	Key(s)
14	Return Return On 0-On 1-Off	Key:	[0] - ON [1] - OFF PRESS [ENTER] TO EDIT NEXT FUNCTION
15	Credi t Sale Debi t Sale Voi d Return	Press:	[ARROW]
16	Pri or Auth Sale Auth Onl y GasCard EBT	Press:	[F1]
17	Pri or Auth Sale Pri or Auth Sale-On 0-On 1Off	Key:	[0] - ON [1] - OFF PRESS [ENTER] TO EDIT NEXT FUNCTION
18	Credi t Sale Debi t Sale Voi d Return	Press:	[ARROW THREE TIMES]
19	Pri or Auth Sale Auth Onl y GasCard EBT	Press:	[F2]
20	Auth Onl y Auth Onl y-On 0-On 1-Off	Key:	[0] - ON [1] - OFF PRESS [ENTER] TO EDIT NEXT FUNCTION
21	Credi t Sale Debi t Sale Voi d Return	Press:	[ARROW THREE TIMES]
22	Pri or Auth Sale Auth Onl y GasCard EBT	Press:	[F3]
23	Gas Card Gas Card On 0-On 1-Off	Key:	[0] - ON [1] - OFF PRESS [ENTER] TO EDIT NEXT FUNCTION
24	Credi t Sale Debi t Sale Voi d Return	Press:	[ARROW THREE TIMES]
25	Pri or Auth Sale Auth Onl y GasCard EBT	Press:	[F4]

Step	Display	Action	Key(s)
26	Credit Sale Debit Sale Void Return	Press:	[ARROW THREE TIMES]
27	Prior Auth Sale Auth Only GasCard EBT	Press:	[ARROW]
28	Issue/Add Value Pr Iss/Add Value Redemption Prior Redempt	Press:	[F1]
29	Issue/Add Value Issue/Add Value-On 0-On 1-Off	Key:	[0] - ON [1] - OFF PRESS [ENTER] TO EDIT NEXT FUNCTION
30	Credit Sale Debit Sale Void Return	Press:	[ARROW FOUR TIMES]
31	Issue/Add Value Pr Iss/Add Value Redemption Prior Redempt	Press:	[F2]
32	Pr Iss/Add Value Pr Iss/Add Value-On 0-On 1-Off	Key:	[0] - ON [1] - OFF PRESS [ENTER] TO EDIT NEXT FUNCTION
33	Credit Sale Debit Sale Void Return	Press:	[ARROW FOUR TIMES]
34	Issue/Add Value Pr Iss/Add Value Redemption Prior Redempt	Press:	[F3]
35	Redemption Redemption-On 0-On 1-Off	Key:	[0] - ON [1] - OFF PRESS [ENTER] TO EDIT NEXT FUNCTION
36	Credit Sale Debit Sale Void Return	Press:	[ARROW FOUR TIMES]
37	Issue/Add Value Pr Iss/Add Value Redemption Prior Redempt	Press:	[F4]
38	Prior Redempt Prior Redempt-On 0-On 1-Off	Key:	[0] - ON [1] - OFF PRESS [ENTER] TO EDIT NEXT FUNCTION

Step	Display	Action	Key(s)
39	Credi t Sale Debi t Sale Voi d Return	Press:	[ARROW FOUR TIMES]
40	I ssue/Add Val ue Pr I ss/Add Val ue Redempti on Pri or Redempt	Press:	[ARROW]
41	Bal ance I nqui ry SV Voi d Debi t Return	Press:	[F1]
42	Bal ance I nqui ry Bal ance I nqui ry-On 0-On 1-Off	Key:	[0] - ON [1] - OFF PRESS [ENTER] TO EDIT NEXT FUNCTION
43	Credi t Sale Debi t Sale Voi d Return	Press:	[ARROW FOUR TIMES]
44	I ssue/Add Val ue Pr I ss/Add Val ue Redempti on Pri or Redempt	Press:	[ARROW]
45	Bal ance I nqui ry SV Voi d Debi t Return	Press:	[F2]
46	SV Voi d SV Voi d-On 0-On 1-Voi d	Key:	[0] - ON [1] - OFF PRESS [ENTER] TO EDIT NEXT FUNCTION
47	Credi t Sale Debi t Sale Voi d Return	Press:	[ARROW FOUR TIMES]
48	I ssue/Add Val ue Pr I ss/Add Val ue Redempti on Pri or Redempt	Press:	[ARROW]
49	Bal ance I nqui ry SV Voi d Debi t Return	Press:	[F3]
50	Debi t Return Debi t Return On 0-On 1-Off	Key:	[0] - ON [1] - OFF PRESS [ENTER] TO EDIT NEXT FUNCTION

Passwords On/Off - H32P14R

Step	Display	Action	Key(s)
1	Idle Prompt	Press:	[ARROW]
2	Void Return Prior Auth Sale EBT	Press:	[ARROW]
3	Auth Only Terminal Maint Terminal Setup System Detail	Press:	[F3]
4	Print Config. Printer/Headers Prompts Phone Numbers	Press:	[ARROW TWICE]
5	Functions On/Off Passwords On/Off Duplicate Check	Press:	[F2]
6	Credit Sale Debit Sale Void Return	Press:	[F1]
7	Credit Sale None 0 - None 1 - Mgmt 2 - Super	Key:	[0] - NO PASSWORD [1] - MANAGEMENT [2] - SUPER PASSWORD PRESS [ENTER] TO EDIT NEXT PASSWORD
8	Credit Sale Debit Sale Void Return	Press:	[F2]
9	Debit Sale None 0 - None 1 - Mgmt 2 - Super	Key:	[0] - NO PASSWORD [1] - MANAGEMENT [2] - SUPER PASSWORD PRESS [ENTER] TO EDIT NEXT PASSWORD
10	Credit Sale Debit Sale Void Return	Press:	[F3]
11	Void Sale None 0 - None 1 - Mgmt 2 - Super	Key:	[0] - NO PASSWORD [1] - MANAGEMENT [2] - SUPER PASSWORD PRESS [ENTER] TO EDIT NEXT PASSWORD
12	Credit Sale Debit Sale Void Return	Press:	[F4]

Step	Display	Action	Key(s)
13	Return Sale None 0 - None 1 - Mgmt 2 - Super	Key:	[0] - NO PASSWORD [1] - MANAGEMENT [2] - SUPER PASSWORD PRESS [ENTER] TO EDIT NEXT PASSWORD
14	Credit Sale Debit Sale Void Return	Press:	[ARROW]
15	Prior Auth Sale Auth Only Shift Maint Batch Maint	Press:	[F1]
16	Prior Auth Sale None 0 - None 1 - Mgmt 2 - Super	Key:	[0] - NO PASSWORD [1] - MANAGEMENT [2] - SUPER PASSWORD PRESS [ENTER] TO EDIT NEXT PASSWORD
17	Credit Sale Debit Sale Void Return	Press:	[ARROW]
18	Prior Auth Sale Auth Only Shift Maint Batch Maint	Press:	[F2]
19	Auth Only None 0 - None 1 - Mgmt 2 - Super	Key:	[0] - NO PASSWORD [1] - MANAGEMENT [2] - SUPER PASSWORD PRESS [ENTER] TO EDIT NEXT PASSWORD
20	Credit Sale Debit Sale Void Return	Press:	[ARROW]
21	Prior Auth Sale Auth Only Shift Maint Batch Maint	Press:	[F3]
22	Shift Maint. None 0 - None 1 - Mgmt 2 - Super	Key:	[0] - NO PASSWORD [1] - MANAGEMENT [2] - SUPER PASSWORD PRESS [ENTER] TO EDIT NEXT PASSWORD
23	Credit Sale Debit Sale Void Return	Press:	[ARROW]

Step	Display	Action	Key(s)
24	Prior Auth Sale Auth Only Shift Maint Batch Maint	Press:	[F4]
25	Batch Maint. None 0 - None 1 - Mgmt 2 Super	Key:	[0] - NO PASSWORD [1] - MANAGEMENT [2] - SUPER PASSWORD PRESS [ENTER] TO EDIT NEXT PASSWORD
26	Credit Sale Debit Sale Void Return	Press:	[ARROW TWICE]
27	Admin Terminal Setup GasCard EBT	Press:	[F1]
28	Admin None 0 - None 1 - Mgmt 2 - Super	Key:	[0] - NO PASSWORD [1] - MANAGEMENT [2] - SUPER PASSWORD PRESS [ENTER] TO EDIT NEXT PASSWORD
29	Credit Sale Debit Sale Void Return	Press:	[ARROW TWICE]
30	Admin Terminal Setup GasCard EBT	Press:	[F2]
31	Terminal Setup None 0 - None 1 - Mgmt 2 - Super	Key:	[0] - NO PASSWORD [1] - MANAGEMENT [2] - SUPER PASSWORD PRESS [ENTER] TO EDIT NEXT PASSWORD
32	Credit Sale Debit Sale Void Return	Press:	[ARROW TWICE]
33	Admin Terminal Setup GasCard EBT	Press:	[F3]

Step	Display	Action	Key(s)
34	GasCard None 0 - None 1 - Mgmt 2 - Super	Key:	[0] - NO PASSWORD [1] - MANAGEMENT [2] - SUPER PASSWORD PRESS [ENTER] TO EDIT NEXT PASSWORD
35	Credi t Sale Debi t Sale Voi d Return	Press:	[ARROW TWICE]
36	Admi n Termi nal Setup GasCard EBT	Press:	[F4]
37	EBT None 0 - None 1 - Mgmt 2 - Super	Key:	[0] - NO PASSWORD [1] - MANAGEMENT [2] - SUPER PASSWORD PRESS [ENTER] TO EDIT NEXT PASSWORD
38	Credi t Sale Debi t Sale Voi d Return	Press:	[ARROW THREE TIMES]
39	I ssue/Add Val ue Pr I ss/Add Val ue Redempti on Pri or Redempt	Press:	[F1]
40	I ssuance/Add Val ue None 0 - None 1 - Mgmt 2 - Super	Key:	[0] - NO PASSWORD [1] - MANAGEMENT [2] - SUPER PASSWORD PRESS [ENTER] TO EDIT NEXT PASSWORD
41	Credi t Sale Debi t Sale Voi d Return	Press:	[ARROW THREE TIMES]
42	I ssue/Add Val ue Pr I ss/Add Val ue Redempti on Pri or Redempt	Press:	[F2]
43	PR I ss/Add Val ue None 0 - None 1 - Mgmt 2 - Super	Key:	[0] - NO PASSWORD [1] - MANAGEMENT [2] - SUPER PASSWORD PRESS [ENTER] TO EDIT NEXT PASSWORD
44	Credi t Sale Debi t Sale Voi d Return	Press:	[ARROW THREE TIMES]

Step	Display	Action	Key(s)
45	Issue/Add Value Pr Issue/Add Value Redemption Prior Redempt	Press:	[F3]
46	Redemption None 0 - None 1 - Mgmt 2 - Super	Key:	[0] - NO PASSWORD [1] - MANAGEMENT [2] - SUPER PASSWORD PRESS [ENTER] TO EDIT NEXT PASSWORD
47	Issue/Add Value Pr Issue/Add Value Redemption Prior Redempt	Press:	[F4]
48	Prior Redemption None 0 - None 1 - Mgmt 2 - Super	Key:	[0] - NO PASSWORD [1] - MANAGEMENT [2] - SUPER PASSWORD PRESS [ENTER] TO EDIT NEXT PASSWORD
49	Credit Sale Debit Sale Void Return	Press:	[ARROW FOUR TIMES]
50	Balance Inquiry SV Void Reprint Ticket Reports	Press:	[F1]
51	Balance Inquiry None 0 - None 1 - Mgmt 2 - Super	Key:	[0] - NO PASSWORD [1] - MANAGEMENT [2] - SUPER PASSWORD PRESS [ENTER] TO EDIT NEXT PASSWORD
52	Credit Sale Debit Sale Void Return	Press:	[ARROW FOUR TIMES]
53	Balance Inquiry SV Void Reprint Ticket Reports	Press:	[F2]
54	SV Void None 0 - None 1 - Mgmt 2 - Super	Key:	[0] - NO PASSWORD [1] - MANAGEMENT [2] - SUPER PASSWORD PRESS [ENTER] TO EDIT NEXT PASSWORD
55	Credit Sale Debit Sale Void Return	Press:	[ARROW FOUR TIMES]

Step	Display	Action	Key(s)
56	Balance Inquiry SV Void Reprint Ticket Reports	Press:	[F3]
57	Reprint Ticket None 0 - None 1 - Mgmt 2 - Super	Key:	[0] - NO PASSWORD [1] - MANAGEMENT [2] - SUPER PASSWORD PRESS [ENTER] TO EDIT NEXT PASSWORD
58	Credit Sale Debit Sale Void Return	Press:	[ARROW FOUR TIMES]
59	Balance Inquiry SV Void Reprint Ticket Reports	Press:	[F4]
60	Reports None 0 - None 1 - Mgmt 2 - Super	Key:	[0] - NO PASSWORD [1] - MANAGEMENT [2] - SUPER PASSWORD PRESS [ENTER] TO EDIT NEXT PASSWORD
61	Credit Sale Debit Sale Void Return	Press:	[ARROW FIVE TIMES]
62	Prod Price Rep Debit Return Enter Mgr Pword	Press:	[F1]
63	Product Price Report None 0 - None 1 - Mgmt 2 - Super	Key:	[0] - NO PASSWORD [1] - MANAGEMENT [2] - SUPER PASSWORD PRESS [ENTER] TO EDIT NEXT PASSWORD
64	Credit Sale Debit Sale Void Return	Press:	[ARROW FIVE TIMES]
65	Prod Price Rep Debit Return Enter Mgr Pword	Press:	[F2]
66	Debit Return Debit Return Supr 0-None 1-Mgmt 2-Supr		[0] - NO PASSWORD [1] - MANAGEMENT [2] - SUPER PASSWORD PRESS [ENTER] TO EDIT NEXT PASSWORD

Step	Display	Action	Key(s)
67	Credi t Sale Debi t Sale Voi d Return	Press:	[ARROW FIVE TIMES]
68	Prod Pri ce Rep Debi t Return Enter Mgr Pword	Press:	[F3]
69	Enter Manager Pswd None 0 - None 1 - Mgmt 2 - Super	Key:	[0] – NO PASSWORD [1] – MANAGEMENT [2] – SUPER PASSWORD PRESS [ENTER] TO EDIT NEXT PASSWORD

Product Maintenance - H32P14R

Step	Display	Action	Key(s)
1	Sale Admin Shift or Batch	Press:	[F3]
2	Training Mode Product Maintenance	Press:	[F2]
3	Product Maint Func/Bksp Scroll F3-Edit F4-Delete	Press:	[ENTER]
4	Product Maint Regular .00 01 Price \$ 1.599	Press:	[ENTER] TO SCROLL TO NEXT PRODUCT [F3] TO EDIT PRODUCT PRICE [F4] TO DELETE PRODUCT
5	Product Maint Enter Unit Price	Key:	PRODUCT PRICE
6	Product Maint Regular .00 01 Price \$ 1.599	Press:	PRESS [ENTER] TO UPDATE NEXT PRODUCT PRESS [CLEAR] TO RETURN TO IDLE PROMPT

Shift or Batch Maintenance - H32P14R

Step	Display	Action	Key(s)
1	Sale Admin Shift or Batch	Press:	[F4]
2	Shift Rpt/Close Batch Rpt/Close	Press:	[F1]
3	Shift Report Shift Close	Press:	[F1] PRINTS SHIFT CLOSE REPORT
4	Shift Report Shift Close	Press:	[F2] PRINTS SHIFT CLOSE REPORT
5	Shift Rpt/Close Batch Rpt/Close	Press:	[F2]
6	Print Review Batch Inquire Settle Batch Clear Batch	Press:	[F1] PRINTS TRANSACTIONS
7	Print Review Batch Inquire Settle Batch Clear Batch	Press:	[F2] PRINTS TRANSACTIONS
8	Print Review Batch Inquire Settle Batch Clear Batch	Press:	[F3] SETTLES THE BATCH
9	Print Review Batch Inquire Settle Batch Clear Batch	Press:	[F4] CLEARS THE BATCH
10	Enter Super Pswd	Key:	LAST 4 DIGITS OF MERCHANT NUMBER
11	Clear Batch? F3 Yes / F4 NO	Press:	[F3] - YES [F4] - NO PRESS [CLEAR] TO RETURN TO IDLE PROMPT

Terminal Setup Mode - H32P14S

To access and make changes in the terminal setup mode, please use the following steps.

Printer/Headers - H32P14S

Step	Display	Action	Key(s)
1	Idle Prompt	Press:	[ARROW]
2	Shift or Batch Void Return Prior Auth Sale	Press:	[ARROW]
3	EBT Auth Only Terminal Maint Terminal Setup	Press:	[F4]
4	Print Config. Printer/Headers Prompts Phone Numbers	Press:	[F2]
5	Printer PIN Pad Encryption RCPT 2 Delay	Press:	[F1]
6	Printer Printer - On 0-Off 1-On	Key:	[0] - OFF [1] - ON PRESS [ENTER] TO RETURN TO PREVIOUS MENU
7	Printer PIN Pad Encryption RCPT 2 Delay	Press:	[F2]
8	PIN Pad PIN Pad - On 0-Off 1-On	Key:	[0] - OFF [1] - ON PRESS [ENTER] TO RETURN TO PREVIOUS MENU
9	Printer PIN Pad Encryption RCPT 2 Delay	Press:	[F3]
10	Encryption Encryption-DUKPT 0-Masterkey 1- DUKPT	Key:	[0] - MASTERKEY [1] - DUKPT PRESS [ENTER] TO RETURN TO PREVIOUS MENU

Step	Display	Action	Key(s)
11	Printer PIN Pad Encryption Rcpt 2 Del ay	Press:	[F4]
12	Rcpt 2 Del ay 5	Key:	NONE PRESS [ENTER] TO RETURN TO PREVIOUS MENU
13	Printer PIN Pad Encryption RCPT 2 Del ay	Press:	[ARROW]
14	Recei pt Opti ons Print 2 Reports DBT/EBT Cash Back Print Headers	Press:	[F1]
15	Recei pt Opti ons Recei pt opti ons- M&C 0-None 1-M&C 2-MO 3-C	Key:	[0] - None [1] - M&C [2] - MO [1] - C PRESS [ENTER] TO RETURN TO PREVIOUS MENU
16	Printer PIN Pad Encryption RCPT 2 Del ay	Press:	[ARROW]
17	Recei pt Opti ons Print 2 Reports DBT/EBT Cash Back Print Headers	Press	[F2]
18	Print 2 Reports Print 2 Reports- Off 0-Off 1-On	Key:	[0] - OFF [1] - ON PRESS [ENTER] TO RETURN TO PREVIOUS MENU
19	Printer PIN Pad Encryption RCPT 2 Del ay	Press:	[ARROW]
20	Recei pt Opti ons Print 2 Reports DBT/EBT Cash Back Print Headers	Press:	[F3]
21	DBT/EBT Cash Back DBT/EBT Cash Back- No 0-No 1-Yes	Key:	[0] - NO [1] - YES PRESS [ENTER] TO RETURN TO PREVIOUS MENU
22	Printer PIN Pad Encryption RCPT 2 Del ay	Press:	[ARROW]

Step	Display	Action	Key(s)
23	Recei pt Opti ons Print 2 Reports Debi t Cash Back Print Headers	Press:	[F4]
24	Print Headers Header #1 Merchant Number	Key:	MERCHANT NUMBER PRESS [ENTER] TO EDIT NEXT OPTION
25	Header #2 Merchant Name	Key:	MERCHANT NAME PRESS [ENTER] TO EDIT NEXT OPTION
26	Header #3 Merchant Address	Key:	MERCHANT ADDRESS PRESS [ENTER] TO EDIT NEXT OPTION
27	Header #4 Merchant Ci ty, State, ZI P	Key:	MERCHANT CITY, STATE, ZIP PRESS [ENTER] TO EDIT NEXT OPTION
28	Header #5 Merchant Phone Number	Key:	MERCHANT PHONE NUMBER PRESS [ENTER] TO EDIT NEXT OPTION
29	Header #6 Merchant Data	Key:	MERCHANT DATA PRESS [ENTER] TO RETURN TO PRINT HEADERS MENU
30	Printer PI N Pad Encrypti on RCPT 2 Del ay	Press:	[ARROW]
31	Recei pt Opti ons Print 2 Reports DBT/EBT Cash Back Print Headers	Press:	[ARROW]
32	Print Di scl ai mer Printer Footers Cust Copy Si gn	Press:	[F1]
33	Print Di scl ai mrs Di scl ai mer #1 I agree to pay above	Key:	ENTER IN DISCLAIMER #1 PRESS [ENTER] TO EDIT NEXT OPTION
34	Print Di scl ai mrs Di scl ai mer #2 Accordi ng to card i ssuer agreement	Key:	ENTER IN DISCLAIMER #2 PRESS [ENTER] TO EDIT NEXT OPTION
35	Print Di scl ai mrs Di scl ai mer #3 (Merchant agreement i f credi t)	Key:	ENTER IN DISCLAIMER #3 PRESS [ENTER] TO EDIT NEXT OPTION

Step	Display	Action	Key(s)
36	Printer PIN Pad Encryption RCPT 2 Delay	Press:	[ARROW]
37	Receipt Options Print 2 Reports DBT/EBT Cash Back Print Headers	Press:	[ARROW]
38	Print Disclaimer Print Footers Cust Copy Sign	Press:	[F2]
39	Print Footers Footer #1 Merchant Data	Key:	ENTER MERCHANT DATA PRESS [ENTER] TO EDIT NEXT OPTION
40	Print Footers Footer #2 Merchant Data	Key:	ENTER MERCHANT DATA PRESS [ENTER] TO EDIT NEXT OPTION
41	Print Footers Footer #3 Merchant Data	Key:	ENTER MERCHANT DATA PRESS [ENTER] TO EDIT NEXT OPTION
42	Print Footers Footer #4 Merchant Data	Key:	ENTER MERCHANT DATA PRESS [ENTER] TO EDIT NEXT OPTION
43	Printer PIN Pad Encryption RCPT 2 Delay	Press:	[ARROW]
44	Receipt Options Print 2 Reports DBT/EBT Cash Back Print Headers	Press:	[ARROW]
45	Print Disclaimer Printer Footers Cust Copy Sign	Press:	[F3]
46	Cust Copy Sign Cust Copy Sign-On 0-Off 1-On	Press:	[0]-OFF [1]-ON PRESS [ENTER] TO RETURN TO PREVIOUS MENU

Prompts - H32P14S

Step	Display	Action	Key(s)
1	Idle Prompt	Press:	[ARROW]
2	Shift or Batch Void Return Prior Auth Sale	Press:	[ARROW]
3	EBT Auth Only Terminal Maint Terminal Setup	Press:	[F4]
4	Print Config. Printer/Headers Prompts Phone Numbers	Press:	[F3]
5	App Mode PINPad Prompt Ask For Serv Ask For Gallons	Press:	[F1]
6	App Mode App Mode-Petro 0-Petro 1-Retail 2-Retail w/Fleet	Key:	[0]-PETRO APPLICATION [1]-RETAIL [2]-RETAIL W/ FLEET PRESS [ENTER] TO RETURN TO PREVIOUS MENU
7	App Mode PINPad Prompt Ask For Serv Ask For Gallons	Press:	[F2]
8	PIN Pad Prompt Welcome	Key:	PIN PAD IDLE PROMPT PRESS [ENTER] TO RETURN TO PROMPTS MENU
9	App Mode PINPad Prompt Ask For Serv Ask For Gallons	Press:	[F3]
10	Ask For Serv Ask For Serv-Yes 0-No 1-Yes	Key:	ASK FOR SERVE - YES 0 - NO 1 - YES PRESS [ENTER] TO RETURN TO PROMPTS MENU
11	App Mode PINPad Prompt Ask For Serv Ask For Gallons	Press:	[F4]

Step	Display	Action	Key(s)
12	Ask For Gallons Ask For Gallons-None 0-None 1-GC Only 2-All	Key:	ASK FOR GALLONS-NONE 0-NONE 1-GC (Gas Card) ONLY 2-All PRESS [ENTER] TO RETURN TO PROMPTS MENU
13	App Mode PINPad Prompt Ask For Serv Ask For Gallons	Press:	[ARROW]
14	Prompt For Tax Keyboard Beep Timeout SV MOD 10 Check	Press:	[F1]
15	Prompt for Tax Prompt for Tax-No 0-No 1-Yes	Key:	[0] - NO [1] - YES PRESS [ENTER] TO RETURN TO PROMPTS MENU
16	Prompt For Tax Keyboard Beep Timeout SV MOD 10 Check	Press:	[F2]
17	Keyboard Beep Keyboard Beep-Off 0-Off 1-On	Key:	[0] - OFF [1] - ON PRESS [ENTER] TO RETURN TO PROMPTS MENU
18	Prompt For Tax Keyboard Beep Timeout SV MOD 10 Check	Press:	[F3]
19	Timeout 60	Press:	TIMEOUT VALUE PRESS [ENTER] TO RETURN TO PROMPTS MENU
20	Prompt For Tax Keyboard Beep Timeout SV MOD 10 Check	Press:	[F4]
21	SV MOD 10 Check SV MOD 10 Check-Yes 0- NO 1-Yes	Key:	STORED VALUE CARD MOD 10 CHECK [0] = NO [1] = YES PRESS [ENTER] TO RETURN TO PROMPTS MENU
22	App Mode PINPad Prompt Ask For Serv Ask For Gallons	Press:	[ARROW]

Step	Display	Action	Key(s)
23	Prompt For Tax Keyboard Beep Ti meout SV MOD 10 Check	Press:	[ARROW]
24	SV Cash out Ask Last 4 Di gi t Ask Ask Press Send Cust Ref #	Press:	[F1]
25	SV Cash Out Ask SV Cash Out Ask-No 0-No 1-Yes	Key:	[0] = NO [1] = YES PRESS [ENTER] TO RETURN TO PROMPTS MENU
26	App Mode PI NPad Prompt Ask For Serv Ask For Gal l ons	Press:	[ARROW]
27	Prompt For Tax Keyboard Beep Ti meout SV MOD 10 Check	Press:	[ARROW]
28	SV Cash out Ask Last 4 Di gi t Ask Ask Press Send Cust Ref #	Press:	[F2]
29	Last 4 Di gi t Ask Last 4 Di gi t Ask- Yes 0-No 1-Yes	Key:	[0] = NO [1] = YES PRESS [ENTER] TO RETURN TO PROMPTS MENU
30	App Mode PI NPad Prompt Ask For Serv Ask For Gal l ons	Press:	[ARROW]
31	Prompt For Tax Keyboard Beep Ti meout SV MOD 10 Check	Press:	[ARROW]
32	SV Cash out Ask Last 4 Di gi t Ask Ask Press Send Cust Ref #	Press:	[F3]
33	Ask for Serv Ask for Serv-No 0-No 1-Yes	Key:	[0] = NO [1] = YES PRESS [ENTER] TO RETURN TO PROMPTS MENU
34	App Mode PI NPad Prompt Ask For Serv Ask For Gal l ons	Press:	[ARROW]
35	Prompt For Tax Keyboard Beep Ti meout SV MOD 10 Check	Press:	[ARROW]

Step	Display	Action	Key(s)
36	SV Cash out Ask Last 4 Di gi t Ask Ask Press Send Cust Ref #	Press:	[F4]
37	Cust Ref # Cust Ref #- No 0-No 1-Yes	Key:	[0] = NO [1] = YES PRESS [ENTER] TO RETURN TO PROMPTS MENU

Phone Numbers - H32P14S

Step	Display	Action	Key(s)
1	Idle Prompt	Press:	[ARROW]
2	Shift or Batch Void Return Prior Auth Sale	Press:	[ARROW]
3	EBT Auth Only Terminal Maint. Terminal Setup	Press:	[F4]
4	Print Config. Printer/Headers Prompts Phone Numbers	Press:	[F4]
5	Primary Phone # Alt Phone # Download Phone #	Press:	[F1]
6	Primary Phone # *****	Key:	PRIMARY PHONE NUMBER OR, PRESS [ENTER] TO RETURN TO PHONE NUMBER MENU
7	Primary Phone Number	Press:	[ENTER]
8	Primary Phone # Alt Phone # Download Phone #	Press:	[F2]
9	Alt Phone # *****	Key:	ALTERNATE PHONE NUMBER OR, PRESS [ENTER] TO RETURN TO PHONE NUMBER MENU
10	Alternate Phone Number	Press:	[ENTER]
11	Primary Phone # Alt Phone # Download Phone #	Press:	[F3]
12	Download Phone # 18003629020	Key:	DOWNLOAD PHONE NUMBER OR, PRESS [ENTER] TO RETURN TO PHONE NUMBER MENU

Dial Type - H32P14S

Step	Display	Action	Key(s)
1	Idle Prompt	Press:	[ARROW]
2	Shift or Batch Void Return Prior Auth Sale	Press:	[ARROW]
3	EBT Auth Only Terminal Maint Terminal Setup	Press:	[F4]
4	Print Config. Printer/Headers Prompts Phone Numbers	Press:	[ARROW]
5	Comm/Dial Merchant Info Product Key Map Setup BIN Table	Press:	[F1]
6	Comm Type Dial Type Dial Speed Modem Speed	Press:	[F1]
7	Comm Type Comm Type-Dial 0-Dial 1-DTR 2-AT	Press:	0-DIAL 1-DTR 2-AT PRESS [ENTER] TO RETURN TO COMM/DIAL MENU
8	Comm Type Dial Type Dial Speed Modem Speed	Press:	[F2]
9	Dial Type Dial Type-Tone 0-Pulse 1-Tone	Key:	[0] - PULSE [1] - TONE PRESS [ENTER] TO RETURN TO COMM/DIAL MENU
10	Comm Type Dial Type Dial Speed Modem Speed	Press:	[F3]
11	Dial Speed Dial Speed-Slow 0-Slow 1-Fast	Key:	[0] - SLOW [1] - FAST PRESS [ENTER] TO RETURN TO COMM/DIAL MENU
12	Comm Type Dial Type Dial Speed Modem Speed	Press:	[F4]

Step	Display	Action	Key(s)
13	Modem Speed Modem Speed- 1200 0- 300 1- 1200	Key:	[0] - 300 [1] - 1200 PRESS [ENTER] TO RETURN TO COMM/DIAL MENU
14	Comm Type Di al Type Di al Speed Modem Speed	Press:	[ARROW]
15	Seri al Num Predi al ?	Press:	[F1]
16	Seri al Num *****	Key:	DOWNLOAD FILE NAME PRESS [ENTER] TO RETURN TO COMM/DIAL MENU
18	Comm Type Di al Type Di al Speed Modem Speed	Press:	[ARROW]
19	Seri al Num Predi al ?	Press:	[F2]
20	Predi al ? Predi al ?- No 0-No 1-Yes	Key:	[0] = NO [1] = YES PRESS [ENTER] TO RETURN TO COMM/DIAL MENU

Merchant Info - H32P14S

Step	Display	Action	Key(s)
1	Idle Prompt	Press:	[ARROW]
2	Shift or Batch Void Return Prior Auth Sale	Press:	[ARROW]
3	EBT Auth Only Terminal Maint Terminal Setup	Press:	[F4]
4	Print Config. Printer/Headers Prompts Phone Numbers	Press:	[ARROW]
5	Comm/Dial Merchant Info Product Keymap Setup BIN Table	Press:	[F2]
6	Client # Merchant # Terminal #	Press:	[F1]
7	Client # ****	Key:	4-DIGIT PNS CLIENT NUMBER PRESS [ENTER] TO RETURN TO MERCHANT INFO MENU
8	Client # Merchant # Terminal #	Press:	[F2]
9	Merchant # *****	Key:	12-DIGIT PNS MERCHANT NUMBER PRESS [ENTER] TO RETURN TO MERCHANT INFO MENU
10	Client # Merchant # Terminal #	Press:	[F3]
11	Terminal # ***	Key:	3-DIGIT TERMINAL ID PRESS [CLEAR] TO RETURN TO IDLE PROMPT

Product Key Map - H32P14S

Step	Display	Action	Key(s)
1	Idle Prompt	Press:	[ARROW]
2	Shift or Batch Void Return Prior Auth Sale		[ARROW]
3	EBT Auth Only Terminal Maint Terminal Setup	Press:	[F4]
4	Print Config. Printer/Headers Prompts Phone Numbers	Press:	[ARROW]
5	Comm/Dial Merchant Info Product Keymap Setup BIN Table	Press:	[F3]
6	Product Key Map KEY #1 1	Key:	PRODUCT CODE KEY SHOULD EQUAL NUMBER PRESS [ENTER] FOR NEXT PRODUCT KEY
7	Product Key Map KEY #2 2	Key:	PRODUCT CODE KEY SHOULD EQUAL PRESS [ENTER] FOR NEXT PRODUCT KEY
8	Product Key Map KEY #3 3	Key:	PRODUCT CODE KEY SHOULD EQUAL PRESS [ENTER] FOR NEXT PRODUCT KEY
9	Product Key Map KEY #4 4	Key:	PRODUCT CODE KEY SHOULD EQUAL PRESS [ENTER] FOR NEXT PRODUCT KEY
10	Product Key Map KEY #5 5	Key:	PRODUCT CODE KEY SHOULD EQUAL PRESS [ENTER] FOR NEXT PRODUCT KEY
11	Product Key Map KEY #6 6	Key:	PRODUCT CODE KEY SHOULD EQUAL
12	Product Key Map KEY #7 7	Key:	PRODUCT CODE KEY SHOULD EQUAL PRESS [ENTER] FOR NEXT PRODUCT KEY

Step	Display	Action	Key(s)
13	Product Key Map KEY #8 8	Key:	PRODUCT CODE KEY SHOULD EQUAL PRESS [ENTER] FOR NEXT PRODUCT KEY
14	Product Key Map KEY #9 9	Key:	PRODUCT CODE KEY SHOULD EQUAL PRESS [ENTER] TO RETURN TO IDLE PROMPT

Setup BIN Tables - H32P14S

Step	Display	Action	Key(s)
1	Idle Prompt	Press:	[ARROW]
2	Shift or Batch Void Return Prior Auth Sale	Press:	[ARROW]
3	EBT Auth Only Terminal Maint Terminal Setup	Press:	[F4]
4	Print Config. Printer/Headers Prompts Phone Numbers	Press:	[ARROW]
5	Comm/Dial Merchant Info Product Keymap Setup BIN Table	Press:	[F4]
6	Setup BIN Table Debit = Capture 0 - Not Acpt 1 - Auth Only 2 - Capture	Key:	[0] - NOT ACCEPT [1] - AUTH ONLY [2] - CAPTURE PRESS [ENTER] TO EDIT NEXT BIN RANGE
7	Setup BIN Table EBT = Capture 0 - Not Acpt 1 - Auth Only 2 - Capture	Key:	[0] - NOT ACCEPT [1] - AUTH ONLY [2] - CAPTURE PRESS [ENTER] TO EDIT NEXT BIN RANGE
8	Setup BIN Table Stored Value = Capture 0 - Not Acpt 1 - Auth Only 2 - Capture	Key:	[0] - NOT ACCEPT [1] - AUTH ONLY [2] - CAPTURE PRESS [ENTER] TO EDIT NEXT BIN RANGE
9	Setup BIN Table MasterCard = Capture 0 - Not Acpt 1 - Auth Only 2 - Capture	Key:	[0] - NOT ACCEPT [1] - AUTH ONLY [2] - CAPTURE PRESS [ENTER] TO EDIT NEXT BIN RANGE
10	Setup BIN Table Visa = Capture 0 - Not Acpt 1 - Auth Only 2 - Capture	Key:	[0] - NOT ACCEPT [1] - AUTH ONLY [2] - CAPTURE PRESS [ENTER] TO EDIT NEXT BIN RANGE

Step	Display	Action	Key(s)
11	Setup BI N Tabl e Vi sa = Capture 0 - Not Acpt 1 - Auth Onl y 2 - Capture	Key:	[0] - NOT ACCEPT [1] - AUTH ONLY [2] - CAPTURE PRESS [ENTER] TO EDIT NEXT BIN RANGE
12	Setup BI N Tabl e MasterCard = Capture 0 - Not Acpt 1 - Auth Onl y 2 - Capture	Key:	[0] - NOT ACCEPT [1] - AUTH ONLY [2] - CAPTURE PRESS [ENTER] TO EDIT NEXT BIN RANGE
13	Setup BI N Tabl e AMEX = Capture 0 - Not Acpt 1 - Auth Onl y 2 - Capture	Key:	[0] - NOT ACCEPT [1] - AUTH ONLY [2] - CAPTURE PRESS [ENTER] TO EDIT NEXT BIN RANGE
14	Setup BI N Tabl e AMEX = Capture 0 - Not Acpt 1 - Auth Onl y 2 - Capture	Key:	[0] - NOT ACCEPT [1] - AUTH ONLY [2] - CAPTURE PRESS [ENTER] TO EDIT NEXT BIN RANGE
15	Setup BI N Tabl e Di scover = Capture 0 - Not Acpt 1 - Auth Onl y 2 - Capture	Key:	[0] - NOT ACCEPT [1] - AUTH ONLY [2] - CAPTURE PRESS [ENTER] TO EDIT NEXT BIN RANGE
16	Setup BI N Tabl e Di ners = Capture 0 - Not Acpt 1 - Auth Onl y 2 - Capture	Key:	[0] - NOT ACCEPT [1] - AUTH ONLY [2] - CAPTURE PRESS [ENTER] TO EDIT NEXT BIN RANGE
17	Setup BI N Tabl e Di ners = Capture 0 - Not Acpt 1 - Auth Onl y 2 - Capture	Key:	[0] - NOT ACCEPT [1] - AUTH ONLY [2] - CAPTURE PRESS [ENTER] TO EDIT NEXT BIN RANGE

Step	Display	Action	Key(s)
18	Setup BI N Tabl e Di ners = Capture 0 - Not Acpt 1 - Auth Onl y 2 - Capture	Key:	[0] - NOT ACCEPT [1] - AUTH ONLY [2] - CAPTURE PRESS [ENTER] TO EDIT NEXT BIN RANGE
19	Setup BI N Tabl e Carte Bl an = Capture 0 - Not Acpt 1 - Auth Onl y 2 - Capture	Key:	[0] - NOT ACCEPT [1] - AUTH ONLY [2] - CAPTURE PRESS [ENTER] TO EDIT NEXT BIN RANGE
20	Setup BI N Tabl e JCB = Capture 0 - Not Acpt 1 - Auth Onl y 2 - Capture	Key:	[0] - NOT ACCEPT [1] - AUTH ONLY [2] - CAPTURE PRESS [ENTER] TO EDIT NEXT BIN RANGE
21	Setup BI N Tabl e JCB = Capture 0 - Not Acpt 1 - Auth Onl y 2 - Capture	Key:	[0] - NOT ACCEPT [1] - AUTH ONLY [2] - CAPTURE PRESS [ENTER] TO EDIT NEXT BIN RANGE
22	Setup BI N Tabl e Wri ght EXP = Capture 0 - Not Acpt 1 - Auth Onl y 2 - Capture	Key:	[0] - NOT ACCEPT [1] - AUTH ONLY [2] - CAPTURE PRESS [ENTER] TO EDIT NEXT BIN RANGE
23	Setup BI N Tabl e Wri ght EXP = Capture 0 - Not Acpt 1 - Auth Onl y 2 - Capture	Key:	[0] - NOT ACCEPT [1] - AUTH ONLY [2] - CAPTURE PRESS [ENTER] TO EDIT NEXT BIN RANGE
24	Setup BI N Tabl e Voyager = Capture 0 - Not Acpt 1 - Auth Onl y 2 - Capture	Key:	[0] - NOT ACCEPT [1] - AUTH ONLY [2] - CAPTURE PRESS [ENTER] TO EDIT NEXT BIN RANGE

Step	Display	Action	Key(s)
25	Setup BIN Table Irving Oil = Capture 0 - Not Acpt 1 - Auth Only 2 - Capture	Key:	[0] - NOT ACCEPT [1] - AUTH ONLY [2] - CAPTURE PRESS [ENTER] TO RETURN TO IDLE PROMPT

Functions On/Off - H32P14S

Step	Display	Action	Key(s)
1	Idle Prompt	Press:	[ARROW]
2	Shift or Batch Void Return Prior Auth Sale	Press:	[ARROW]
3	EBT Auth Only Terminal Maint Terminal Setup	Press:	[F4]
4	Print Config. Printer/Headers Prompts Phone Numbers	Press:	[ARROW]
5	Comm/Dial Merchant Info Product Keymap Setup BIN Table	Press:	[ARROW]
6	Functions On/Off Passwords On/Off Duplicate Check	Press:	[F1]
7	Credit Sale Debit Sale Void Return	Press:	[F1]
8	Credit Sale - On 0-On 1-Off	Press:	[0] - ON [1] - OFF PRESS [ENTER] TO RETURN TO FUNCTION MENU
9	Credit Sale Debit Sale Void Return	Press:	[F2]
10	Debit Sale - On 0-On 1-Off	Key:	[0] - ON [1] - OFF PRESS [ENTER] TO RETURN TO FUNCTION MENU
11	Credit Sale Debit Sale Void Return	Press:	[F3]
12	Void- On 0-On 1-Off	Key:	[0] - ON [1] - OFF PRESS [ENTER] TO RETURN TO FUNCTION MENU
13	Credit Sale Debit Sale Void Return	Press:	[F4]

Step	Display	Action	Key(s)
14	Return - On 0-On 1-Off	Key:	[0] - ON [1] - OFF PRESS [ENTER] TO RETURN TO FUNCTION MENU
15	Credi t Sale Debi t Sale Voi d Return	Press:	[ARROW]
16	Pri or Auth Sale Auth Onl y Gascard EBT	Press:	[F1]
17	Pri or Auth Sale-On 0-On 1-Off	Key:	[0] - ON [1] - OFF PRESS [ENTER] TO RETURN TO FUNCTION MENU
18	Credi t Sale Debi t Sale Voi d Return	Press:	[ARROW]
19	Pri or Auth Sale Auth Onl y Gascard EBT	Press:	[F2]
20	Auth Onl y-On 0-On 1-Off	Key:	[0] - ON [1] - OFF PRESS [ENTER] TO RETURN TO FUNCTION MENU
21	Credi t Sale Debi t Sale Voi d Return	Press:	[ARROW]
22	Pri or Auth Sale Auth Onl y Gascard EBT	Press:	[F3]
23	Gas Card - Off 0-On 1-Off	Key:	[0] - ON [1] - OFF PRESS [ENTER] TO RETURN TO FUNCTION MENU
24	Credi t Sale Debi t Sale Voi d Return	Press:	[ARROW]
25	Pri or Auth Sale Auth Onl y Gascard EBT	Press:	[F4]

Step	Display	Action	Key(s)
26	EBT - On 0-On 1-Off	Key:	[0] - ON [1] - OFF PRESS [ENTER] TO RETURN TO FUNCTION MENU
27	Credi t Sale Debi t Sale Voi d Return	Press:	[ARROW]
28	Pri or Auth Sale Auth Onl y Gascard EBT	Press:	[ARROW]
29	I ssue/Add Val ue Pr I ss/Add Val ue Redempti on Pri or Redempt	Press:	[F1]
30	I ssue/Add Val ue- On 0-On 1-Off	Key:	[0] - ON [1] - OFF PRESS [ENTER] TO RETURN TO FUNCTION MENU
31	Credi t Sale Debi t Sale Voi d Return	Press:	[ARROW]
32	Pri or Auth Sale Auth Onl y Gascard EBT	Press:	[ARROW]
33	I ssue/Add Val ue Pr I ss/Add Val ue Redempti on Pri or Redempt	Press:	[F2]
34	Pr I ssue/Add Val ue- On 0-On 1-Off	Key:	[0] - ON [1] - OFF PRESS [ENTER] TO RETURN TO FUNCTION MENU
35	Credi t Sale Debi t Sale Voi d Return	Press:	[ARROW]
36	Pri or Auth Sale Auth Onl y Gascard EBT	Press:	[ARROW]
37	I ssue/Add Val ue Pr I ss/Add Val ue Redempti on Pri or Redempt	Press:	[F3]
38	Redempti on- On 0-On 1-Off	Key:	[0] - ON [1] - OFF PRESS [ENTER] TO RETURN TO FUNCTION MENU

Step	Display	Action	Key(s)
39	Credit Sale Debit Sale Void Return	Press:	[ARROW]
40	Prior Auth Sale Auth Only Gascard EBT	Press:	[ARROW]
41	Issue/Add Value Pr Iss/Add Value Redemption Prior Redempt	Press:	[F4]
42	Prior Redemption- On 0-On 1-Off	Key:	[0] - ON [1] - OFF PRESS [ENTER] TO RETURN TO FUNCTION MENU
43	Credit Sale Debit Sale Void Return	Press:	[ARROW]
44	Prior Auth Sale Auth Only Gascard EBT	Press:	[ARROW]
45	Issue/Add Value Pr Iss/Add Value Redemption Prior Redempt	Press:	[ARROW]
46	Balance Inquiry SV Void Debit Return	Press:	[F1]
47	Balance Inquiry-On 0-On 1-Off	Key:	[0] - ON [1] - OFF PRESS [ENTER] TO RETURN TO FUNCTION MENU
48	Credit Sale Debit Sale Void Return	Press:	[ARROW]
49	Prior Auth Sale Auth Only Gascard EBT	Press:	[ARROW]
50	Issue/Add Value Pr Iss/Add Value Redemption Prior Redempt	Press:	[ARROW]
51	Balance Inquiry SV Void Debit Return	Press:	[F2]
52	SV Void-On 0-On 1-Off	Key:	[0] - ON [1] - OFF PRESS [ENTER] TO RETURN TO FUNCTION MENU

Step	Display	Action	Key(s)
54	Credit Sale Debit Sale Void Return	Press:	[ARROW]
55	Prior Auth Sale Auth Only Gascard EBT	Press:	[ARROW]
56	Issue/Add Value Pr Iss/Add Value Redemption Prior Redempt	Press:	[ARROW]
57	Balance Inquiry SV Void Debit Return	Press:	[F3]
58	Debit Return = On 0-On 1-Off	Key:	[0] - ON [1] - OFF PRESS [ENTER] TO RETURN TO FUNCTION MENU

Passwords On/Off - H32P14S

Step	Display	Action	Key(s)
1	Idle Prompt	Press:	[ARROW]
2	Shift or Batch Void Return Prior Auth Sale	Press:	[ARROW]
3	EBT Auth Only Terminal Maint Terminal Setup	Press:	[F4]
4	Print Config. Printer/Headers Prompts Phone Numbers	Press:	[ARROW]
5	Comm/Dial Merchant Info Product Keymap Setup BIN Table	Press:	[ARROW]
6	Functions On/Off Passwords On/Off Duplicate Check	Press:	[F2]
7	Credit Sale Debit Sale Void Return	Press:	[F1]
8	Credit Sale - None 0-None 1-Mgmt 2- Supr	Press:	[0] - NO PASSWORD [1] - MANAGEMENT [2] - SUPER PASSWORD PRESS [ENTER] TO RETURN TO PASSWORD MENU

Step	Display	Action	Key(s)
9	Credi t Sale Debi t Sale Voi d Return	Press:	[F2]
10	Debi t Sale - None 0-None 1-Mgmt 2- Supr	Key:	[0] - NO PASSWORD [1] - MANAGEMENT [2] - SUPER PASSWORD PRESS [ENTER] TO RETURN TO PASSWORD MENU
11	Credi t Sale Debi t Sale Voi d Return	Press:	[F3]
12	Voi d- None 0-None 1-Mgmt 2- Supr	Key:	[0] - NO PASSWORD [1] - MANAGEMENT [2] - SUPER PASSWORD PRESS [ENTER] TO RETURN TO PASSWORD MENU
13	Credi t Sale Debi t Sale Voi d Return	Press:	[F4]
14	Return - None 0-None 1-Mgmt 2- Supr	Key:	[0] - NO PASSWORD [1] - MANAGEMENT [2] - SUPER PASSWORD PRESS [ENTER] TO RETURN TO PASSWORD MENU
15	Credi t Sale Debi t Sale Voi d Return	Press:	[ARROW]
16	Pri or Auth Sale Auth Onl y Shi ft Mai nt Batch Mai nt	Press:	[F1]
17	Pri or Auth Sale- None 0-None 1-Mgmt 2- Supr	Key:	[0] - NO PASSWORD [1] - MANAGEMENT [2] - SUPER PASSWORD PRESS [ENTER] TO RETURN TO PASSWORD MENU
18	Credi t Sale Debi t Sale Voi d Return	Press:	[ARROW]
19	Pri or Auth Sale Auth Onl y Shi ft Mai nt Batch Mai nt	Press:	[F2]

Step	Display	Action	Key(s)
20	Auth Only- None 0-None 1-Mgmt 2- Supr	Key:	[0] - NO PASSWORD [1] - MANAGEMENT [2] - SUPER PASSWORD PRESS [ENTER] TO RETURN TO PASSWORD MENU
21	Credit Sale Debit Sale Void Return	Press:	[ARROW]
22	Prior Auth Sale Auth Only Shift Maint Batch Maint	Press:	[F3]
23	Shift Maint- None 0-None 1-Mgmt 2- Supr	Key:	[0] - NO PASSWORD [1] - MANAGEMENT [2] - SUPER PASSWORD PRESS [ENTER] TO RETURN TO PASSWORD MENU
24	Credit Sale Debit Sale Void Return	Press:	[ARROW]
25	Prior Auth Sale Auth Only Shift Maint Batch Maint	Press:	[F4]
26	Batch Maint- None 0-None 1-Mgmt 2- Supr	Key:	[0] - NO PASSWORD [1] - MANAGEMENT [2] - SUPER PASSWORD PRESS [ENTER] TO RETURN TO PASSWORD MENU
27	Credit Sale Debit Sale Void Return	Press:	[ARROW]
28	Prior Auth Sale Auth Only Shift Maint Batch Maint	Press:	[ARROW]
29	Admin Terminal Setup GasCard EBT	Press:	[F1]
30	Admin- None 0-None 1-Mgmt 2- Supr	Key:	[0] - NO PASSWORD [1] - MANAGEMENT [2] - SUPER PASSWORD PRESS [ENTER] TO RETURN TO PASSWORD MENU

Step	Display	Action	Key(s)
31	Credit Sale Debit Sale Void Return	Press:	[ARROW]
32	Prior Auth Sale Auth Only Shift Maint Batch Maint	Press:	[ARROW]
33	Admin Terminal Setup GasCard EBT	Press:	[F2]
34	Terminal Set up- None 0-None 1-Mgmt 2- Supr	Key:	[0] - NO PASSWORD [1] - MANAGEMENT [2] - SUPER PASSWORD PRESS [ENTER] TO RETURN TO PASSWORD MENU
35	Credit Sale Debit Sale Void Return	Press:	[ARROW]
36	Prior Auth Sale Auth Only Shift Maint Batch Maint	Press:	[ARROW]
37	Admin Terminal Setup GasCard EBT	Press:	[F3]
38	GasCard- None 0-None 1-Mgmt 2- Supr	Key:	[0] - NO PASSWORD [1] - MANAGEMENT [2] - SUPER PASSWORD PRESS [ENTER] TO RETURN TO PASSWORD MENU
39	Credit Sale Debit Sale Void Return	Press:	[ARROW]
40	Prior Auth Sale Auth Only Shift Maint Batch Maint	Press:	[ARROW]
41	Admin Terminal Setup GasCard EBT	Press:	[F4]
42	EBT- None 0-None 1-Mgmt 2- Supr	Key:	[0] - NO PASSWORD [1] - MANAGEMENT [2] - SUPER PASSWORD PRESS [ENTER] TO RETURN TO PASSWORD MENU

Step	Display	Action	Key(s)
43	Credit Sale Debit Sale Void Return	Press:	[ARROW]
44	Prior Auth Sale Auth Only Shift Maint Batch Maint	Press:	[ARROW]
45	Admin Terminal Setup GasCard EBT	Press:	[ARROW]
46	Issue/Add Value Pr Issue/Add Value Redemption Prior Redempt	Press:	[F1]
47	Issue/Add Value- None 0-None 1-Mgmt 2- Supr	Key:	[0] - NO PASSWORD [1] - MANAGEMENT [2] - SUPER PASSWORD PRESS [ENTER] TO RETURN TO PASSWORD MENU
48	Credit Sale Debit Sale Void Return	Press:	[ARROW]
49	Prior Auth Sale Auth Only Shift Maint Batch Maint	Press:	[ARROW]
50	Admin Terminal Setup GasCard EBT	Press:	[ARROW]
51	Issue/Add Value Pr Issue/Add Value Redemption Prior Redempt	Press:	[F2]
52	PR Issue/Add Value-None 0-None 1-Mgmt 2- Supr	Key:	[0] - NO PASSWORD [1] - MANAGEMENT [2] - SUPER PASSWORD PRESS [ENTER] TO RETURN TO PASSWORD MENU
53	Credit Sale Debit Sale Void Return	Press:	[ARROW]
54	Prior Auth Sale Auth Only Shift Maint Batch Maint	Press:	[ARROW]
55	Admin Terminal Setup GasCard EBT	Press:	[ARROW]

	Display	Action	Key(s)
56	Issue/Add Value Pr Iss/Add Value Redemption Pr Redemption	Press:	[F3]
57	Redemption None 0 - None 1 - Mgmt 2 - Super	Key:	[0] - NO PASSWORD [1] - MANAGEMENT [2] - SUPER PASSWORD PRESS [ENTER] TO EDIT NEXT PASSWORD
58	Credit Sale Debit Sale Void Return	Press:	[ARROW]
59	Prior Auth Sale Auth Only Shift Maint Batch Maint	Press:	[ARROW]
60	Admin Terminal Setup GasCard EBT	Press:	[ARROW]
61	Issue/Add Value Pr Iss/Add Value Redemption Prior Redempt	Press:	[F4]
62	Prior Redempti on- None 0-None 1-Mgmt 2- Supr	Key:	[0] - NO PASSWORD [1] - MANAGEMENT [2] - SUPER PASSWORD PRESS [ENTER] TO RETURN TO PASSWORD MENU
63	Credit Sale Debit Sale Void Return	Press:	[ARROW]
64	Prior Auth Sale Auth Only Shift Maint Batch Maint	Press:	[ARROW]
65	Admin Terminal Setup GasCard EBT	Press:	[ARROW]
66	Issue/Add Value Pr Iss/Add Value Redemption Prior Redempt	Press:	[ARROW]
67	Balance Inquiry SV Void Reprint Ticket Reports	Press:	[F1]

Step	Display	Action	Key(s)
68	Balance Inquiry- None 0-None 1-Mgmt 2- Supr	Key:	[0] - NO PASSWORD [1] - MANAGEMENT [2] - SUPER PASSWORD PRESS [ENTER] TO RETURN TO PASSWORD MENU
69	Credit Sale Debit Sale Void Return	Press:	[ARROW]
70	Prior Auth Sale Auth Only Shift Maint Batch Maint	Press:	[ARROW]
71	Admin Terminal Setup GasCard EBT	Press:	[ARROW]
72	Issue/Add Value Pr Iss/Add Value Redemption Prior Redempt	Press:	[ARROW]
73	Balance Inquiry SV Void Reprint Ticket Reports	Press:	[F2]
74	SV Void-None 0-None 1-Mgmt 2- Supr	Key:	[0] - NO PASSWORD [1] - MANAGEMENT [2] - SUPER PASSWORD PRESS [ENTER] TO RETURN TO PASSWORD MENU
75	Credit Sale Debit Sale Void Return	Press:	[ARROW]
76	Prior Auth Sale Auth Only Shift Maint Batch Maint	Press:	[ARROW]
77	Admin Terminal Setup GasCard EBT	Press:	[ARROW]
78	Issue/Add Value Pr Iss/Add Value Redemption Prior Redempt	Press:	[ARROW]
79	Balance Inquiry SV Void Reprint Ticket Reports	Press:	[F3]

Step	Display	Action	Key(s)
80	Reprint Ticket- None 0-None 1-Mgmt 2- Supr	Key:	[0] - NO PASSWORD [1] - MANAGEMENT [2] - SUPER PASSWORD PRESS [ENTER] TO RETURN TO PASSWORD MENU
81	Credit Sale Debit Sale Void Return	Press:	[ARROW]
82	Prior Auth Sale Auth Only Shift Maint Batch Maint	Press:	[ARROW]
83	Admin Terminal Setup GasCard EBT	Press:	[ARROW]
84	Issue/Add Value Pr Iss/Add Value Redemption Prior Redempt	Press:	[ARROW]
85	Balance Inquiry SV Void Reprint Ticket Reports	Press:	[F4]
86	Reports-None 0-None 1-Mgmt 2- Supr	Key:	[0] - NO PASSWORD [1] - MANAGEMENT [2] - SUPER PASSWORD PRESS [ENTER] TO RETURN TO PASSWORD MENU
87	Credit Sale Debit Sale Void Return	Press:	[ARROW]
88	Prior Auth Sale Auth Only Shift Maint Batch Maint	Press:	[ARROW]
89	Admin Terminal Setup GasCard EBT	Press:	[ARROW]
90	Issue/Add Value Pr Iss/Add Value Redemption Prior Redempt	Press:	[ARROW]
91	Balance Inquiry SV Void Reprint Ticket Reports	Press:	[ARROW]
92	Prod Price Report Enter Mgr Password Debit Return	Press:	[F1]

Step	Display	Action	Key(s)
93	Prod Price Rep- None 0-None 1-Mgmt 2- Supr	Key:	[0] - NO PASSWORD [1] - MANAGEMENT [2] - SUPER PASSWORD PRESS [ENTER] TO RETURN TO PASSWORD MENU
94	Credi t Sale Debi t Sale Voi d Return	Press:	[ARROW]
95	Pri or Auth Sale Auth Onl y Shi ft Mai nt Batch Mai nt	Press:	[ARROW]
96	Admi n Termi nal Setup GasCard EBT	Press:	[ARROW]
97	I ssue/Add Val ue Pr I ss/Add Val ue Redempti on Pri or Redempt	Press:	[ARROW]
98	Bal ance Inqui ry SV Voi d Repri nt Ti cket Reports	Press:	[ARROW]
99	Prod Price Report Enter Mgr Password Debi t Return	Press:	[F2]
100	Enter Mgr Password *****	Key:	PASSWORD PRESS [ENTER] TO RETURN TO PASSWORD MENU
101	Credi t Sale Debi t Sale Voi d Return	Press:	[ARROW]
102	Pri or Auth Sale Auth Onl y Shi ft Mai nt Batch Mai nt	Press:	[ARROW]
103	Admi n Termi nal Setup GasCard EBT	Press:	[ARROW]
104	I ssue/Add Val ue Pr I ss/Add Val ue Redempti on Pri or Redempt	Press:	[ARROW]
105	Bal ance Inqui ry SV Voi d Repri nt Ti cket Reports	Press:	[ARROW]
106	Prod Price Report Enter Mgr Password Debi t Return	Press:	[F3]

107	Debit Return=Supr 0- None 1- Mgmt 2- Supr	Key:	[0] - NO PASSWORD [1] - MANAGEMENT [2] - SUPER PASSWORD PRESS [CLEAR] TO RETURN TO IDLE PROMPT
------------	--	------	--

Product Maintenance - H32P14S

Step	Display	Action	Key(s)
1	Sale Admin Stored Value	Press:	[F3]
2	Training Mode Product Maintenance	Press:	[F2]
3	Product Maint Func/Bksp- Scroll F3-Edit F4-Delete	Press:	[ENTER]
4	Product Maint Ethanol 85 01 Price \$ 1.599	Press:	[ENTER] TO SCROLL TO NEXT PRODUCT OR, [F3] TO EDIT PRODUCT PRICE OR, PRESS [CLEAR] TO RETURN TO IDLE PROMPT
5	Product Maint Enter Unit Price	Key:	PRODUCT PRICE, THEN PRESS [ENTER]
6	Product Maint Ethanol 85 01 Price \$ 1.599	Press:	PRESS [ENTER] TO UPDATE NEXT PRODUCT, OR PRESS [CLEAR] TO RETURN TO IDLE PROMPT

Shift or Batch Maintenance – H32P14S

Step	Display	Action	Key(s)
1	Idle Prompt	Press:	[ARROW]
2	Shift or Batch Void Return Prior Auth Sale	Press:	[F1]
3	Shift Rpt/Close Batch Rpt/Close	Press:	[F1]
4	Shift Report Shift Close	Press:	[F1] TO PRINT SHIFT REPORT [F2] TO CLOSE SHIFT PRESS [CLEAR] TO RETURN TO IDLE PROMPT
5	Shift Rpt/Close Batch Rpt/Close	Press:	[F2]
6	Print Review Batch Inquiry Settle Batch Clear Batch	Press:	[F1] PRINTS TRANSACTIONS
7	Print Review Batch Inquiry Settle Batch Clear Batch	Press:	[F2] PRINTS TRANSACTIONS
8	Print Review Batch Inquiry Settle Batch Clear Batch	Press:	[F3] SETTLES THE BATCH
9	Print Review Batch Inquiry Settle Batch Clear Batch	Press:	[F4] CLEARS THE BATCH (SUPERVISOR PASSWORD IS REQUIRED)
8	Enter Super Pswd	Key:	LAST 4 DIGITS OF MERCHANT NUMBER
9	Clear Batch? F3- Yes / F4- NO	Press:	[F3] - YES [F4] - NO PRESS [CLEAR] TO RETURN TO IDLE PROMPT